

Sectional Couch Protector - Covering Panel Protector Section 30" x 23"



Using Your Covering Panel Protector Section – Not for Outdoor Use

The covering panel protector section of the sectional protector is used to cover and protect bumpers and other parts of your sectional that the other protector sections do not cover and protect.

Dimensions:

The covering panel protector section is 30" long x 23" wide.



Step i: Position The Section


Place the covering panel on the part of your sectional couch you want covered. The white soft side of the protector rests against your sectional. The colored fabric side faces up where people, or dogs, will sit.

Step ii: Connecting Sections:

How you connect the covering panel to other sections of the protector will depend on the configuration of your sectional and what part of your sectional you want covered.

Step iii: Connectors

Locate the two connectors that secure the protector sections in place. One side of a connector is the rough "hook" side that attaches to the underside of the protector sections. The other side is the white smooth "loop" side that goes against your sectional couch.



Attach the connectors (with the rough 'hook' side facing up) to the underside of the covering panel so that half the connector is left exposed.

Slowly position the connecting protector section over the connectors and press the connecting section onto the connectors. Reposition as needed.



Continued...



Sectional Couch Protector




Using Your Protector & Washing Instructions

Thanks for purchasing the sectional couch protector. Your four legged best friends will enjoy sleeping on your sectional, and your couch will remain clean and protected for years to come. The protector is fast and easy to put on, take off, and machine wash and dry.

Step 1: Corner and Arms


Remove any throw pillows (do not remove pillows/cushions that are a part of the sectional). Find i. the corner protector section, ii. the left arm section, and iii. the right arm section. Remove these sections from the plastic bags. Position these sections so the white side of the protector rests against your sectional and the corduroy side faces up where people, or dogs, will sit. The Floppy Ears label is on the part of the protector sections where people would normally put their feet. (On the corner section the label is on the seat cushion area.)



Step 2: Corners and Arm Chair Sections

Position the corner, left arm chair and right arm chair protector sections on your sectional couch. In order to get the protector sections in the right position (snug to the edges of the cushions)...

... flip the panels that go over the back rest and the sectional arms onto the seat cushions.



Flipping over the back and arm panels will let you see the seams and allow you to move those seams right up to where the seating cushion meets the back rest cushion (or arm).

Step 3: Insert Rubber Anchors

When you flip over the back and arm panels you'll be able to see the rubber anchors on the back of the protector sections. Push the anchors down in between the cushions to help keep the protector in place.

Continued...




Sectional Couch Protector



Step 4: Positioning the Armless Sections

Next, find the armless chair, and/or armless loveseat protector sections. Take those out of the plastic bags. Position the armless sections over the gaps between the arm chairs and the corner sections. Again, the white side goes down, and the label goes where people's feet would normally be when sitting. For the corner protector sections, position the armless chair sections so the edges of the sections go right up to the edge of the right angle corner of the sectional couch.

Step 4



The armless chair sections go right up to the edge of the right angle corner of the sectional

Flip the panels that go over the back rest and the sectional arms onto the seat cushions. Move the exposed seams so the seams are right against where the seat cushion meets the back rest cushion. Push the anchors down in between the cushions.

Step 4




Move the exposed seams right against the seat cushions. Push the anchors down between the cushions.

Step 5: Connectors

Find the connectors that secure the protector sections in place. One side of a connector is the rough "Hook" side that attaches to the underside of the protector sections. The other side is the white smooth "Loop" side that goes against your sectional couch.

Attach a connector with the rough hook side facing up to the underside of the protector section so half the connector is left exposed. Attach one



connector to the protector panel that rests of the seating cushion and one connector to the panel that rests against the seat back cushion (you may chose to attach more connectors to other parts of the protector sections).

Slowly position the connecting protector section (likely an armless section) in place and press the connecting section onto the connectors.

Reposition as needed.

When you position one section over another section and connect those sections make sure you have at least an 8" overlap of one section over another. This will ensure there is no gap between sections when a person sits on the sectional.

Step 5



Position connectors so half is attached and half is exposed (that will attach to the connecting protector section)

Finally, tie the cords on the arm chair sections.

Continued...




Sectional Couch Protector



Step 6: Sectionals with Armless Chairs

If your sectional couch has armless chairs (that is, some ends of your sectional don't have arms) putting the protector together is fast and easy.



Just as you do with sectionals with arms, position the corner protector sections in place.

Instead of placing the left and right arm chair protector sections in place, position the armless chairs and/or armless loveseat protector sections on the armless end of your sectional. The armless chair or loveseat protector sections will go to the end of your sectional, but will not extend over the sides.

Continue to: fill the gaps with other armless chairs or loveseat; align the seams with where the seat and back rest cushions meet; push in the rubber anchors; and install the connectors.

Washing Instructions:

The protector is fast and easy to clean and dry. Remove the protector from your sectional couch. Separate all the protector sections. Remove all connectors from the sectional protector.

Wash and dry the protector sections separately from other items.

Wash and dry the connectors separately from all other items. You may want to wash the connectors by hand as the connectors will attach to other connectors and other items.

Machine wash the protector sections using cold water on a gentle setting using a mild laundry detergent. Machine dry on a cool setting.

Do not use bleach, do not dry clean, do not use fabric softeners as these may damage the waterproof membrane and fabrics.



Machine wash,
gentle, cool
water



Do not
bleach



Machine
dry, low
heat



Do not
dry clean

If you had a great experience with your new Sectional Couch Protector please tell your friends. If you didn't, please tell us at: info@floppyearsdesign.com.

And, we love dogs. We'd love to see any pictures you have of using your protector!

